

#B41-B501 LOG SET



WARNING: This product can expose you to chemicals including ceramic fiber and/or silica dust which is (are) known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit www.P65Warnings.ca.gov

For use with models BAY-41-BW and BAY-41-MV

CAUTION: Do not place logs directly over burner port holes. Improper log placement may affect flame appearance and cause excessive soot to build upon the logs and glass.

- If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.
- Log numbers are located on the bottom of each log. Refer to the

following instructions and illustrations for proper log placement.

1. Position the ember panel in front of the burner.
2. Align the holes in bottom of base logs (41B-1 to 41B-4) with the mounting pins on the burner. Push logs down onto pins to seat.
3. Align logs 41B-5 and 41B-6 with the notches on the base logs.
4. Align logs 41B-7 and 41B-8 as shown in Figure 1.
5. Use a steel or stiff bristle nylon brush to distribute rock wool embers onto logs and burner.



Figure 1, #B41-B501 Log Set Installation