

#SL42-501 & #SL36-501

For use with models #SLA-42S and #SLA-36

NOTE: Log numbers are located on the bottom of each log accent piece. Refer to the following instructions and illustration for proper placement. Your components may look different than the ones shown.

NOTE: Log accent pieces may be moved or removed to prevent potential sooting. Do not set any log on top of the burner tube shadow.

CAUTION: Do not set log accent pieces directly on top of burner tube shadow. Do not block pilot assembly. This could cause a potentially hazardous situation.

Kit Components:

(7) Driftwood Log Accent Pieces

1. Refer to illustration below for proper placement of the logs.
2. SLAYTON 36:
#109 Glass Beads & #201 Glass Crystals: Install all logs as shown in the picture below with logs on top of the glass.

3. SLAYTON 42S:
#101 Glass Beads & #213 Glass Crystals: For propane installations with minimum horizontal venting, it may be necessary to remove up to 2 lb. (0.9 kg) of glass underneath the back two logs to prevent sooting.
#309 Reflective Glass: Natural gas installations with minimum horizontal venting require to remove 1 lb (0.4536 kg) of reflective glass and adjusting the air shutter opening to 3/16" (4.7mm) on all three burners.
NOTE: Propane installations require the back two logs to be placed directly onto the media tray. Remove 1 lb (0.4536 kg) of reflective glass then install glass onto the media tray. Place the rest of the logs as shown. Remove 50% of the glass off the burner ports.
4. Distribute rockwool embers onto accent pieces and burner using a stiff bristle brush.

