

# #SL42-600 DRIFTWOOD ACCENT KIT

For use with models #SLA-36 and #SLA-42S

**NOTE:** Log numbers are located on the bottom of each log accent piece. Refer to the following instructions and illustration for proper placement. Your components may look different than the ones shown.

**NOTE:** Log accent pieces may be moved or removed to prevent potential sooting. Do not set any log on top of the burner tube shadow.

**CAUTION:** Do not set log accent pieces directly on top of burner tube shadow. Do not block pilot assembly. This could cause a potentially hazardous situation.

Kit Components:

(7) Driftwood Log Accent Pieces

1. Place log #SL42-D1 and #SL42-D2 directly on the burner cover/screen as shown.
2. Install glass media onto the burner cover and pilot shield.

3. #SLA-36: Install a maximum of 10 lb. (4.5 kg) of glass media. When using #309 Reflective Glass install a maximum of 7 lb. (3.175 kg) of glass media.
4. #SLA-42S: Install a maximum of 13 lb. (5.8 kg) of glass media. When using #309 Reflective Glass install a maximum of 8 lb. (3.6 kg) of glass media.
5. Verify glass media layer is one layer deep. Depending on your specific application, such as venting configuration and gas installation, remove up to 75% of glass media covering burner ports for proper flame appearance.
6. Place logs #SL42-D3 through #SL42-D7 as shown.
7. Distribute rockwool embers onto accent pieces and burner using a stiff bristle brush.

