

# #SP41-50A LOG SET

For use with models #SP-41-L, #SP-41-LE, #SP-41-MV

KOZY HEAT  
FIREPLACES  
HUSSONG MANUFACTURING CO., INC.

**WARNING:** This product can expose you to chemicals including ceramic fiber and/or silica dust which is (are) known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

*NOTE: Log numbers are located on the bottom of each log. Refer to the following instructions and illustration for proper placement. Your components may look different than the ones shown.*

*If converting to propane, complete the conversion before installing log set. Follow instructions included with the conversion kit*

1. Place log SP41-1A on the back log plate.
2. Place log SP41-2A on the left front log plate.
3. Place log SP41-3A on the right front log plate.
4. Distribute lava rock into the dip on the heat shield front of the burner and onto the sides of the heat shield. Do not block burner ports or airspaces.
5. Align logs SP34-4A, SP34-5A, SP34-6A with the notches in the base logs as shown.
6. Use a steel or stiff bristle nylon brush to distribute rock wool embers onto logs and burner.

