

#500-RAM

ROCK ACCENT MEDIA

For models #CLW-50, #CLW-50-MV, #CLW-ST

⚠ WARNING: This product can expose you to chemicals including ceramic fiber and/or silica dust which is (are) known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit www.P65Warnings.ca.gov

NOTE: Rock numbers are located on the bottom of each accent piece. Refer to the following instructions and illustration for proper accent piece placement. Your components may look different than the ones shown.

NOTE: Rock accent medias may be moved or removed to prevent potential sooting. Do not set any accent piece on top of the burner tube shadow.

CAUTION: Do not set accent media directly on top of burner ports. Do not block pilot assembly. This could cause a potentially hazardous situation.

KOZY  HEAT
FIREPLACES

Kit Components: (36) Accent Rocks

1. Install an even layer of your chosen media across the whole burner.
2. Install an even layer of media across the front and rear perimeter
3. Place the rock accent media as shown.

