

# #NK34-500 LOG SET

For use with model #NDK-34-i

**WARNING:** This product can expose you to chemicals including ceramic fiber and/or silica dust which is (are) known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**NOTE:** Log numbers are located on the bottom of each log. Refer to the following instructions and illustration for proper placement. Your components may look different than the ones shown.

**CAUTION:** Do not place logs directly over burner port holes. Improper log placement may affect flame appearance and may cause excessive soot to build upon the glass.

- If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.
  - Log numbers located on the bottom of each log. Refer to the following instructions and illustrations for proper placement.
1. Remove (2) 7/16" nuts securing light kit, set light kit to the side. Loosen (2) 7/16" nuts securing left and right burners. Remove burners.
  2. Install refractory panels. Follow instructions included with the kit.
  3. Place log #N34-1 and log #N34-2 on corresponding pins on burner (not shown). Be sure to place N34-1 and N34-2 logs BEFORE placing glass media. Logs must lie flat on media tray and burners. Failure to do so will negatively affect the flame.
  4. Fill back media tray with crushed glass media.
  5. Place log # N34-3 onto log # N34-1 aligning hole in the bottom of log # N34-3 with the corresponding pin on log #N34-1.
  6. Reinstall left burner assembly pushing it towards center until it stops against the rear burner, then secure. Repeat this process with the right burner assembly.
  7. Reinstall light kit and media tray/log rack.
  8. Install log #N34-4 and #N34-5 aligning holes in bottom of logs with corresponding pins on burners.
  9. Place log #N34-6 and Klinkers on burner ensuring burner ports are not covered.
  10. Fill front media tray with crushed glass media. Fill void on either side of media tray with lava rock.
  11. Place log #N34-7 along log rack.
  12. Place Klinkers on crushed glass media on front media tray.
  13. Use a stiff or steel bristle brush to distribute rockwool embers onto the burner and logs. Use ONLY up to 1/2 the bag, save the rest for later use.

