



#435-ICE Crushed Media

For use with model Generation 7220

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Part #435-ICE includes (7) 5lb. Bags of crushed media.

- Burner Media.
 - If you are installing just the crushed glass (no log set) then install 5 bags (25 lbs.) across the burner media tray.
 - If you are installing a log set then install 4 bags (20 lbs.) across the burner media tray. Ensure the crushed glass is only one layer thick across the burner.
- Perimeter Media.
 - Install approximately 1-1/2 bags (7.5 lbs.) across the perimeter media trays.

Rev. 1



#435-ICE Crushed Media

For use with model Generation 7220

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Part #435-ICE includes (7) 5lb. Bags of crushed media.

- Burner Media.
 - If you are installing just the crushed glass (no log set) then install 5 bags (25 lbs.) across the burner media tray.
 - If you are installing a log set then install 4 bags (20 lbs.) across the burner media tray. Ensure the crushed glass is only one layer thick across the burner.
- Perimeter Media.
 - Install approximately 1-1/2 bags (7.5 lbs.) across the perimeter media trays.

Rev. 1



#435-ICE Crushed Media

For use with model Generation 7220

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Part #435-ICE includes (7) 5lb. Bags of crushed media.

- Burner Media.
 - If you are installing just the crushed glass (no log set) then install 5 bags (25 lbs.) across the burner media tray.
 - If you are installing a log set then install 4 bags (20 lbs.) across the burner media tray. Ensure the crushed glass is only one layer thick across the burner.
- Perimeter Media.
 - Install approximately 1-1/2 bags (7.5 lbs.) across the perimeter media trays.

Rev. 1