



#600-715 Lava Rock

For use with model Generation 7220 & Generation 7220 Screen

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Burner Media.

- If you are not installing one of the optional log sets then install the 7-1/2 lb. bag labeled "Burner Media #1" and 3-1/2 lb. bag labeled "Burner Media #2" for a total of 11 lbs. across the burner media tray.
- If you are installing one of the optional log sets then install just the 7-1/2 lb. bag labeled "Burner Media #1" across the burner media tray. Ensure the lava rock is only one layer thick across the burner. It is recommended to install the log set before installing lava rock across the burner media tray.

Perimeter Media.

- Install the 4 lb. bag of lava rock labeled "Perimeter Media" across the perimeter media trays.

Rev. 1



#600-715 Lava Rock

For use with model Generation 7220 & Generation 7220 Screen

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Burner Media.

- If you are not installing one of the optional log sets then install the 7-1/2 lb. bag labeled "Burner Media #1" and 3-1/2 lb. bag labeled "Burner Media #2" for a total of 11 lbs. across the burner media tray.
- If you are installing one of the optional log sets then install just the 7-1/2 lb. bag labeled "Burner Media #1" across the burner media tray. Ensure the lava rock is only one layer thick across the burner. It is recommended to install the log set before installing lava rock across the burner media tray.

Perimeter Media.

- Install the 4 lb. bag of lava rock labeled "Perimeter Media" across the perimeter media trays.

Rev. 1



#600-715 Lava Rock

For use with model Generation 7220 & Generation 7220 Screen

- *If converting to propane, complete the conversion before installing the log set. Follow the conversion instructions included with the kit.*
- *If installing a black glass panel set, complete installation of panel set before log installation*

Burner Media.

- If you are not installing one of the optional log sets then install the 7-1/2 lb. bag labeled "Burner Media #1" and 3-1/2 lb. bag labeled "Burner Media #2" for a total of 11 lbs. across the burner media tray.
- If you are installing one of the optional log sets then install just the 7-1/2 lb. bag labeled "Burner Media #1" across the burner media tray. Ensure the lava rock is only one layer thick across the burner. It is recommended to install the log set before installing lava rock across the burner media tray.

Perimeter Media.

- Install the 4 lb. bag of lava rock labeled "Perimeter Media" across the perimeter media trays.

Rev. 1